



ENSO LAMP


PRODUCT INFORMATION

MOODFORM
www.moodformstudio.com

Read Me

Important Information

- Replace with **low-wattage LED bulbs** only. **8.8W MAX**
- Use UL or ETL listed bulbs only
- Do **NOT** use incandescent, halogen, or other high-heat bulbs.
- Indoor use only. Keep away from water, moisture, direct sunlight, and excessive heat.
- Unplug before changing the bulb, moving the lamp, or handling electrical parts.
- Stop use immediately if you notice damage, unusual heat, odor, discoloration, or frayed wiring.
- Replacement bulbs may vary in dimmer performance



Need Help?

Visit: www.moodformstudio.com
Email: support@moodformstudio.com

Technical Specifications

Dimensions: 5.5"Ø x 8"H

Bulb Compatibility: Low-wattage LED bulb only, 8.8W max

Cord: Black braided E26 cord, 2 m, rated SVT-2, 18 AWG, 10A, 125V.

Dimmer: Inline Rotary Dimmer Switch

Weight: .96 lbs

MOODFORM
www.moodformstudio.com

Product Information

Please follow the recommendations below to avoid potential damage

Lid Tray

The lid tray can be easily removed from the lampshade for use on or off the lamp.

Bulb Replacement:

If the bulb needs to be replaced, simply remove the lid and insert a new bulb.

Lampshade removal is not required. Please follow the safety guidelines for approved bulb types.

Dimmer

Use the dimmer dial to brighten or dim the light to match your mood

Disclaimer & Safety Notice

This product is designed for use with **low-wattage LED bulbs ONLY (maximum 8.8W or less)**.

Only replace with low-wattage, UL/ETL listed LED bulbs.

Do **NOT** use incandescent, halogen, or other high-heat bulbs, as they may cause overheating and damage.

The lamp body includes 3D-printed parts made from heat-sensitive materials.

Do not expose to excessive heat, direct sunlight, or moisture. Indoor use only.

The included LED bulb is provided as a complimentary third-party consumable accessory for initial setup.

Lifespan may vary depending on usage.

Dimmer performance and compatibility may vary by LED bulb.

This product is not a toy. Keep out of reach of children and pets.

Do not leave the lamp unattended while powered on for extended periods.

Do not submerge the lamp in water.

Do not tamper with the electrical components.

Stop use immediately if you notice any signs of damage, unusual odors, discoloration, unusual heat, or frayed wiring.

Please follow these safety guidelines to ensure proper use. Moodform Studio is not responsible for any issues resulting from misuse or unauthorized changes.

Please reach out if you have any questions. Email: support@moodformstudio.com

© Moodform Studio. All rights reserved.